

HOSE ASSEMBLIES

O.E.M. REPLACEMENT HOSE ASSEMBLIES



INTERCHANGE









DISCHARGE, LIQUID, and SUCTION HOSES

OE#	PART#	OE#	PART#	OE#	PART#	OE#	PART#
FREIGHTLINER		FREIGHTLINER		FREIGHTLINER		INTERNATIONAL	
05-19232-300	09-0672	A22-57519-009	09-0667	A22-61340-000	09-0646	3162298-C92	09-0840
05-19232-301	09-0673	A22-57519-010	09-0668	A22-61340-001	09-0636	3536464-C91	09-0821
05-19232-302	09-0674	A22-57536-000	09-0627	A22-62580-000	09-06107	356581-C91	09-0822
05-19233-300	09-0611	A22-57592-000	09-0653	A22-62919-004	09-0614	3582987-C92	09-0824
05-19233-301	09-0612	A22-57592-002	09-0654	A22-62922-002	09-0637	3582989-C91	09-0823
05-19233-302	09-0613	A22-57592-005	09-0655	A22-62925-008	09-0664	3590900-C91	09-0801
A22-41332-051	09-06102	A22-58023-002	09-0603	A22-62926-009	09-0632	3592145-C92	09-0841
A22-47151-002	09-0678	A22-58556-000	09-0628	A22-62926-010	09-0647	3600647-C-91	09-0800
A22-52177-000	09-0606	A22-58556-001	09-0629	A22-62926-011	09-0632	3612296-C92	09-0820
A22-52177-300	09-0604	A22-59078-021	09-06103	A22-62928-004	09-0607		
A22-52177-308	09-0604	A22-59078-029	09-0608	A22-63675-002	09-0638	PACCAR	
A22-52177-331	09-0601	A22-59190-001	09-0604	A22-63684-000	09-0661	KW / Peterbilt	
A22-52177-342	09-0609	A22-59696-003	09-0602	A22-63801-000	09-06100	18-04130-038	09-1403
A22-52178-300	09-0620	A22-59791-003	09-0651	A22-64009-001	09-0610	18-04130-042	09-1404
A22-52178-304	09-0621	A22-59792-001	09-0630	A22-64057-000	09-0639	18-04130-050	09-1405
A22-52178-308	09-0622	A22-59792-003	09-06306	A22-64057-002	09-0649	18-04132-029	09-1400
A22-52178-309	09-0623	A22-59792-004	09-0631	A22-65586-000	09-0640	18-04132-035	09-1401
A22-52178-314	09-0624	A22-59808-002	09-06104	A22-65939-000	09-0615	D9027-2830	09-1403
A22-52178-319	09-0625	A22-59809-000	09-0642	A22-65975-000	09-06101	D9027-2834	09-1404
A22-52178-335	09-0633	A22-59933-000	09-0666	A22-66192-000	09-0616	D9027-2842	09-1405
A22-52178-336	09-0634	A22-59934-000	09-0675	A22-66221-000	09-0617	D9027-3121	09-1400
A22-52178-338	09-0635	A22-59958-000	09-0643	A22-66221-001	09-0618	D9027-3127	09-1401
A22-52178-340	09-0626	A22-59999-003	09-0671	A22-66384-000	09-0641	D9027-8891	09-1402
A22-52200-001	09-0656	A22-59999-001	09-0662	A22-66631-000	09-0619	D9031-1478	09-1000
A22-52200-301	09-0656	A22-60079-000	09-06105	A22-66632-101	09-06300	D9031-1541	09-1021
A22-57504-001	09-0657	A22-60080-002	09-0644	A22-66834-004	09-06301	D9031-1543	09-1020
A22-57504-002	09-0658	A22-60081-002	09-0676	A22-66834-008	09-06302	D9031-1546	09-1022
A22-57505-000	09-0663	A22-60156-001	09-0677	A22-67862-000	09-06303	D9031-1549	09-1021
A22-57505-001	09-0670	A22-60361-001	09-0660	A22-68540-000	09-06304	D9031-1552	09-1020
A22-57506-002	09-0659	A22-60405-000	09-06106			D9032-3618	09-1024
A22-57519-000	09-0669	A22-60416-001	09-0645			F50-1653-0930	09-1050
A22-57519-001	09-0652	A22-60416-004	09-06305			F50-6054-1425	09-1402
						K342-805-1050-055-0	09-1023

A/C HOSE ASSEMBLY

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number.

 <p>09-0601 SUCTION HOSE Freightliner Century Class/Columbia OE# A22-52177-331</p>	 <p>09-0602 SUCTION HOSE Freightliner Columbia OE# A22-59696-003</p>
 <p>09-0603 SUCTION HOSE Freightliner M2 OE# A22-58023-002</p>	 <p>09-0604 SUCTION HOSE Freightliner Columbia OE# A22-52177-300, A22-52177-308, A22-59190-001</p>
 <p>09-0606 SUCTION HOSE Freightliner Columbia OE# A22-52177-000</p>	 <p>09-0607 LIQUID HOSE #8 - J-BLOCK to DRIER (#7559) Freightliner Columbia w/Detroit 60 engine OE# A22-62928-004</p>
 <p>09-0608 SUCTION HOSE Freightliner A/C Hose OE# A22-59078-029</p>	 <p>09-0609 SUCTION HOSE Freightliner Columbia OE# A22-52177-342</p>

A/C HOSE ASSEMBLY

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

A/C HOSE ASSEMBLY



09-0610
 SUCTION TUBE
 Freightliner
 OE# A22-64009-001



09-0611
 SUCTION TUBE
 Replaces approx. 100" long aluminum style
 Freightliner
 OE# 05-19233-300



09-0612
 SUCTION TUBE
 Replaces approx. 110" long aluminum style
 Freightliner
 OE# 05-19233-301



09-0613
 SUCTION TUBE
 Replaces approx. 120" long aluminum style
 Freightliner
 OE# 05-19233-302



09-0614
 SUCTION TUBE
 Freightliner
 OE# A22-62919-004



09-0615
 SUCTION TUBE
 Freightliner
 OE# A22-65939-000











09-0616
 SUCTION TUBE
 Freightliner
 OE# A22-66192-000



09-0617
 SUCTION TUBE
 Freightliner
 OE# A22-66221-000

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

 <p>09-0618 SUCTION TUBE Freightliner OE# A22-66221-001</p>	 <p>09-0619 SUCTION TUBE Freightliner OE# A22-66631-000</p>
 <p>09-0620 DISCHARGE HOSE Freightliner Century Class/Columbia OE# A22-52178-300</p>	 <p>09-0621 DISCHARGE HOSE Freightliner Columbia OE# A22-52178-304</p>
 <p>09-0622 DISCHARGE HOSE Freightliner Columbia OE# A22-52178-308</p>	 <p>09-0623 DISCHARGE HOSE Freightliner a/c hose OE# A22-52178-309</p>
 <p>09-0624 DISCHARGE HOSE Freightliner OE# A22-52178-314</p>	 <p>09-0625 DISCHARGE HOSE Freightliner Century Class OE# A22-52178-319</p>

A/C HOSE ASSEMBLY

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

A/C HOSE ASSEMBLY




09-0626
DISCHARGE HOSE
Freightliner Columbia
OE# A22-52178-340




09-0627
DISCHARGE HOSE
Freightliner A/C Hose
OE# A22-57536-000




09-0628
DISCHARGE HOSE
Freightliner M2/Cat 3126
OE# A22-58556-000



09-0629
DISCHARGE HOSE
Freightliner M2
OE# A22-58556-001



09-0630
DISCHARGE HOSE
Freightliner Columbia
OE# A22-59792-001



09-0631
DISCHARGE HOSE
Freightliner Columbia
OE# A22-59792-004











09-0632
DISCHARGE HOSE
Freightliner Columbia w/Detroit 60 engine
OE# A22-62926-009; A22-62926-011



09-0633
DISCHARGE HOSE
Freightliner A/C Hose
OE# A22-52178-335

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

 <p>09-0634 DISCHARGE HOSE Freightliner Columbia OE# A22-52178-336</p>	 <p>09-0635 DISCHARGE HOSE Freightliner A/C Hose OE# A22-52178-338</p>
 <p>09-0636 DISCHARGE HOSE / DRIER to J-BLOCK Freightliner Columbia OE# A22-61340-001</p>	 <p>09-0637 DISCHARGE HOSE Freightliner OE# A22-62922-002</p>
 <p>09-0638 DISCHARGE HOSE Freightliner OE# A22-63675-002</p>	 <p>09-0639 DISCHARGE HOSE Freightliner OE# A22-64057-000</p>
 <p>09-0640 DISCHARGE HOSE Freightliner OE# A22-65586-000</p>	 <p>09-0641 DISCHARGE HOSE Freightliner OE# A22-66384-000</p>

A/C HOSE ASSEMBLY

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

A/C HOSE ASSEMBLY



09-0642
DISCHARGE HOSE
Freightliner
OE# A22-59809-000



09-0643
DISCHARGE HOSE
Freightliner
OE# A22-59958-000



09-0644
DISCHARGE HOSE
Freightliner
OE# A22-60080-002



09-0645
DISCHARGE HOSE
Freightliner
OE# A22-60416-001



09-0646
DISCHARGE HOSE
Freightliner
OE# A22-61340-000



09-0647
DISCHARGE HOSE
Freightliner
OE# A22-62926-010











09-0648 reorder 09-0632
DISCHARGE HOSE
Freightliner
OE# A22-62926-011



09-0649
DISCHARGE HOSE
Freightliner
OE# A22-64057-002

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

 <p>09-0651 LIQUID HOSE / DRIER to CONDENSER Freightliner Century Class/Columbia OE# A22-59791-003</p>	 <p>09-0652 LIQUID HOSE Freightliner Century Class/Columbia/Coronado OE# A22-57519-001</p>
 <p>09-0653 LIQUID HOSE Freightliner Century Class/Columbia/Coronado OE# A22-57592-000</p>	 <p>09-0654 LIQUID HOSE Freightliner Century Class/Columbia OE# A22-57592-002</p>
 <p>09-0655 LIQUID HOSE Freightliner Columbia OE# A22-57592-005</p>	 <p>09-0656 LIQUID HOSE / DRIER to CONDENSER Freightliner Columbia OE# A22-52200-301, A22-52200-001</p>
 <p>09-0657 LIQUID HOSE / DRIER to CONDENSER Freightliner M2 OE# A22-57504-001</p>	 <p>09-0658 LIQUID HOSE / DRIER to CONDENSER Freightliner M2 OE# A22-57504-002</p>

A/C HOSE ASSEMBLY


HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

A/C HOSE ASSEMBLY



09-0659
LIQUID HOSE
Freightliner A/C Hose
OE# A22-57506-002




09-0660
LIQUID HOSE / DRIER to CONDENSER
Freightliner Columbia
OE# A22-60361-001




09-0661
LIQUID HOSE / DRIER to CONDENSER
Freightliner Columbia w/Detroit 60 engine
OE# A22-63684-000



09-0662
LIQUID HOSE / DRIER to EVAPORATOR
Freightliner Columbia
OE# A22-59999-001



09-0663
LIQUID HOSE / DRIER to J-BLOCK
Freightliner M2
OE# A22-57505-000



09-0664
LIQUID HOSE / DRIER to J-BLOCK
Freightliner Columbia w/Detroit 60 engine
OE# A22-62925-008











09-0666
LIQUID HOSE / DRIER to J-BLOCK
Freightliner Columbia
OE# A22-59933-000



09-0667
LIQUID HOSE / DRIER to J-BLOCK
Freightliner A/C Hose
OE# A22-57519-009

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

 <p>09-0668 LIQUID HOSE / DRIER to J-BLOCK Freightliner A/C Hose OE# A22-57519-010</p>	 <p>09-0669 LIQUID HOSE / DRIER to J-BLOCK Freightliner A/C Hose OE# A22-57519-000</p>
 <p>09-0670 LIQUID HOSE Freightliner A/C Hose OE# A22-57505-001</p>	 <p>09-0671 LIQUID HOSE Freightliner A/C Hose OE# A22-59999-003</p>
 <p>09-0672 LIQUID HOSE Replaces approx. 100" long aluminum style Freightliner OE# 05-19232-300</p>	 <p>09-0673 LIQUID HOSE Replaces approx. 110" long aluminum style Freightliner OE# 05-19232-301</p>
 <p>09-0674 LIQUID HOSE Replaces approx. 120" long aluminum style Freightliner OE# 05-19232-302</p>	 <p>09-0675 LIQUID HOSE Freightliner OE# A22-59934-000</p>

A/C HOSE ASSEMBLY

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).


A/C HOSE ASSEMBLY



09-0676
LIQUID HOSE
Freightliner
OE# A22-60081-002



09-0677
LIQUID HOSE
Freightliner
OE# A22-60156-001



09-0678
LIQUID HOSE
Freightliner
OE# A22-47151-002



09-0800
SUCTION HOSE
Navistar ProStar
OE# 3600647-C91



09-0801
SUCTION HOSE
Navistar Prostar
OE# 3590900-C91



09-0820
DISCHARGE HOSE
Navistar ProStar
OE# 3612296-C92











09-0821
DISCHARGE HOSE
Navistar Prostar
OE# 3565464-C91



09-0822
DISCHARGE HOSE
Navistar Prostar
OE# 3565481-C91

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

 <p>09-0823 DISCHARGE HOSE Navistar Prostar OE# 3582989-C91</p>	 <p>09-0824 DISCHARGE HOSE Navistar Prostar OE# 3582987-C92</p>
 <p>w/o switch</p> <p>09-0840 LIQUID HOSE Navistar ProStar OE# 3612298-C92</p>	 <p>09-0841 LIQUID HOSE Navistar Prostar OE# 3592145-C92</p>
 <p>09-1000 SUCTION HOSE Kenworth OE# D9031-1478</p>	 <p>09-1020 DISCHARGE HOSE Length of hose: 43-1/4" Kenworth OE# D9031-1552; D9031-1543</p>
 <p>09-1021 DISCHARGE HOSE Length of hose: 47-1/4" Kenworth OE# D9031-1549; D9031-1541</p>	 <p>09-1022 DISCHARGE HOSE Length of hose: 50-1/4" Kenworth OE# D9031-1546</p>

A/C HOSE ASSEMBLY

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

A/C HOSE ASSEMBLY



09-1023
DISCHARGE HOSE
Kenworth
OE# K342-805-1050-055-0



09-1024
DISCHARGE HOSE
Kenworth
OE# D9032-3618



09-1050
LIQUID HOSE
Kenworth
OE# F50-1653-0930



09-1400
DISCHARGE HOSE
Peterbilt
OE# D9027-3121; 18-04132-029



09-1401
DISCHARGE HOSE
Peterbilt
OE# D9027-3127; 18-04132-035



09-1402
DISCHARGE HOSE
Peterbilt
OE# D9027-8891; F50-6054-1425











09-1403
DISCHARGE HOSE
Peterbilt
OE# D9027-2830; 18-04130-038



09-1404
DISCHARGE HOSE
Peterbilt
OE# D9027-2834; 18-04130-042

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

 <p>09-1405 DISCHARGE HOSE Peterbilt OE# D9027-2842; 18-04130-050</p>	 <p>09-06100 SUCTION TUBE Freightliner OE# A22-63801-000</p>
 <p>09-06101 SUCTION HOSE Freightliner OE# A22-65975-000</p>	 <p>09-06102 SUCTION TUBE Freightliner OE# A22-41322-051</p>
 <p>09-06103 SUCTION HOSE Freightliner OE# A22-59078-021</p>	 <p>09-06104 SUCTION TUBE Freightliner OE# A22-59808-002 NOTE: Protector not included</p>
 <p>09-06105 SUCTION TUBE Freightliner OE# A22-60079-000</p>	 <p>09-06106 SUCTION TUBE Freightliner OE# A22-60405-000</p>

A/C HOSE ASSEMBLY

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

A/C HOSE ASSEMBLY



09-06107
SUCTION TUBE
Freightliner
OE# A22-62580-000



09-06300
DISCHARGE HOSE
Freightliner
OE# A22-66632-101



09-06301
DISCHARGE HOSE
Freightliner
OE# A22-66834-004



09-06302
DISCHARGE HOSE
Freightliner
OE# A22-66834-008



09-06303
DISCHARGE HOSE
Freightliner
OE# A22-67862-000



09-06304
DISCHARGE HOSE
Freightliner
OE# A22-68540-000



09-06305
DISCHARGE HOSE
Freightliner
OE# A22-60416-004



09-06306
DISCHARGE HOSE
Freightliner
OE# A22-59792-003