

O.E.M. REPLACEMENT HOSE ASSEMBLIES



INTERCHANGE

DISCHARGE, LIQUID, and SUCTION HOSES

OE#	PART#	OE#	PART#	OE#	PART#	OE#	PART#
FREIGHTLINER		FREIGHTLINER		FREIGHTLINER		INTERNATIONAL	
05-19232-300	09-0672	A22-57592-000	09-0653	A22-62919-004	09-0614	3612298-C92	09-0840
05-19232-301	09-0673	A22-57592-002	09-0654	A22-62922-002	09-0637	3565464-C91	09-0821
05-19232-302	09-0674	A22-57592-005	09-0655	A22-62925-008	09-0664	3565481-C91	09-0822
A22-41332-051	09-06102	A22-58023-002	09-0603	A22-62926-009	09-0632	3582987-C92	09-0824
A22-47151-002	09-0678	A22-58556-000	09-0628	A22-62926-010	09-0647	3582989-C91	09-0823
A22-52177-000	09-0606	A22-58556-001	09-0629	A22-62926-011	09-0632	3590900-C91	09-0801
A22-52177-300	09-0604	A22-59078-021	09-06103	A22-62928-004	09-0607	3592145-C92	09-0841
A22-52177-308	09-0604	A22-59078-029	09-0608	A22-63675-002	09-0638	3600647-C-91	09-0800
A22-52177-331	09-0601	A22-59190-001	09-0604	A22-63684-000	09-0661	3612296-C92	09-0820
A22-52177-342	09-0609	A22-59696-003	09-0602	A22-63801-000	09-06100		
A22-52178-300	09-0620	A22-59791-003	09-0651	A22-64009-001	09-0610	PACCAR	
A22-52178-304	09-0621	A22-59792-001	09-0630	A22-64057-000	09-0639	KW / Peterbilt	
A22-52178-308	09-0622	A22-59792-003	09-06306	A22-64057-002	09-0649	18-04130-038	09-1403
A22-52178-309	09-0623	A22-59792-004	09-0631	A22-65586-000	09-0640	18-04130-042	09-1404
A22-52178-314	09-0624	A22-59808-002	09-06104	A22-65939-000	09-0615	18-04130-050	09-1405
A22-52178-319	09-0625	A22-59809-000	09-0642	A22-65975-000	09-06101	18-04132-029	09-1400
A22-52178-335	09-0633	A22-59933-000	09-0666	A22-66192-000	09-0616	18-04132-035	09-1401
A22-52178-336	09-0634	A22-59934-000	09-0675	A22-66221-000	09-0617	D9027-2830	09-1403
A22-52178-338	09-0635	A22-59958-000	09-0643	A22-66221-001	09-0618	D9027-2834	09-1404
A22-52178-340	09-0626	A22-59999-003	09-0671	A22-66384-000	09-0641	D9027-2842	09-1405
A22-52200-001	09-0656	A22-59999-001	09-0662	A22-66416-100	09-06108	D9027-3121	09-1400
A22-52200-301	09-0656	A22-60079-000	09-06105	A22-66631-000	09-0619	D9027-3127	09-1401
A22-57504-001	09-0657	A22-60080-002	09-0644	A22-66632-101	09-06300	D9027-8891	09-1402
A22-57504-002	09-0658	A22-60081-002	09-0676	A22-66834-004	09-06301	D9031-1478	09-1000
A22-57505-000	09-0663	A22-60156-001	09-0677	A22-66834-008	09-06302	D9031-1541	09-1021
A22-57505-001	09-0670	A22-60361-001	09-0660	A22-67862-000	09-06303	D9031-1543	09-1020
A22-57506-002	09-0659	A22-60405-000	09-06106	A22-68540-000	09-06304	D9031-1546	09-1022
A22-57519-000	09-0669	A22-60416-001	09-0645	A22-71406-200	09-06108	D9031-1549	09-1021
A22-57519-001	09-0652	A22-60416-004	09-06305	A22-71408-203	09-06307	D9031-1552	09-1020
A22-57519-009	09-0667	A22-61340-000	09-0646			D9032-3618	09-1024
A22-57519-010	09-0668	A22-61340-001	09-0636			F50-1653-0930	09-1050
A22-57536-000	09-0627	A22-62580-000	09-06107			F50-6054-1425	09-1402
						F50-6242-1475	09-1406
						K342-805-1050-055-0	09-1023

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number.

A/C HOSE ASSEMBLY



09-0601
 SUCTION HOSE
 Freightliner Century Class/Columbia
 OE# A22-52177-331



09-0602
 SUCTION HOSE
 Freightliner Columbia
 OE# A22-59696-003



09-0603
 SUCTION HOSE
 Freightliner M2
 OE# A22-58023-002



09-0604
 SUCTION HOSE
 Freightliner Columbia
 OE# A22-52177-300, A22-52177-308, A22-59190-001



09-0606
 SUCTION HOSE
 Freightliner Columbia
 OE# A22-52177-000



09-0607
 LIQUID HOSE #8 - J-BLOCK to DRIER (#7559)
 Freightliner Columbia w/Detroit 60 engine
 OE# A22-62928-004











09-0608
 SUCTION HOSE
 Freightliner A/C Hose
 OE# A22-59078-029



09-0609
 SUCTION HOSE
 Freightliner Columbia
 OE# A22-52177-342

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

 <p>09-0610 SUCTION TUBE Freightliner OE# A22-64009-001</p>	 <p>09-0614 SUCTION TUBE Freightliner OE# A22-62919-004</p>
 <p>09-0615 SUCTION TUBE Freightliner OE# A22-65939-000</p>	 <p>09-0616 SUCTION TUBE Freightliner OE# A22-66192-000</p>
 <p>09-0617 SUCTION TUBE Freightliner OE# A22-66221-000</p>	 <p>09-0618 SUCTION TUBE Freightliner OE# A22-66221-001</p>
 <p>09-0619 SUCTION TUBE Freightliner OE# A22-66631-000</p>	 <p>09-0620 DISCHARGE HOSE Freightliner Century Class/Columbia OE# A22-52178-300</p>

A/C HOSE ASSEMBLY

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

A/C HOSE ASSEMBLY



09-0621
DISCHARGE HOSE
Freightliner Columbia
OE# A22-52178-304



09-0622
DISCHARGE HOSE
Freightliner Columbia
OE# A22-52178-308



09-0623
DISCHARGE HOSE
Freightliner a/c hose
OE# A22-52178-309



09-0624
DISCHARGE HOSE
Freightliner
OE# A22-52178-314



09-0625
DISCHARGE HOSE
Freightliner Century Class
OE# A22-52178-319



09-0626
DISCHARGE HOSE
Freightliner Columbia
OE# A22-52178-340











09-0627
DISCHARGE HOSE
Freightliner A/C Hose
OE# A22-57536-000



09-0628
DISCHARGE HOSE
Freightliner M2/Cat 3126
OE# A22-58556-000

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

 <p>09-0629 DISCHARGE HOSE Freightliner M2 OE# A22-58556-001</p>	 <p>09-0630 DISCHARGE HOSE Freightliner Columbia OE# A22-59792-001</p>
 <p>09-0631 DISCHARGE HOSE Freightliner Columbia OE# A22-59792-004</p>	 <p>09-0632 DISCHARGE HOSE Freightliner Columbia w/Detroit 60 engine OE# A22-62926-009; A22-62926-011</p>
 <p>09-0633 DISCHARGE HOSE Freightliner A/C Hose OE# A22-52178-335</p>	 <p>09-0634 DISCHARGE HOSE Freightliner Columbia OE# A22-52178-336</p>
 <p>09-0635 DISCHARGE HOSE Freightliner A/C Hose OE# A22-52178-338</p>	 <p>09-0636 DISCHARGE HOSE / DRIER to J-BLOCK Freightliner Columbia OE# A22-61340-001</p>

A/C HOSE ASSEMBLY

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

A/C HOSE ASSEMBLY




09-0637
DISCHARGE HOSE
Freightliner
OE# A22-62922-002



09-0638
DISCHARGE HOSE
Freightliner
OE# A22-63675-002



09-0639
DISCHARGE HOSE
Freightliner
OE# A22-64057-000



09-0640
DISCHARGE HOSE
Freightliner
OE# A22-65586-000



09-0641
DISCHARGE HOSE
Freightliner
OE# A22-66384-000



09-0642
DISCHARGE HOSE
Freightliner
OE# A22-59809-000











09-0643
DISCHARGE HOSE
Freightliner
OE# A22-59958-000



09-0644
DISCHARGE HOSE
Freightliner
OE# A22-60080-002

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

 <p>09-0645 DISCHARGE HOSE Freightliner OE# A22-60416-001</p>	 <p>09-0646 DISCHARGE HOSE Freightliner OE# A22-61340-000</p>
 <p>09-0647 DISCHARGE HOSE Freightliner OE# A22-62926-010</p>	 <p>09-0649 DISCHARGE HOSE Freightliner OE# A22-64057-002</p>
 <p>09-0651 LIQUID HOSE / DRIER to CONDENSER Freightliner Century Class/Columbia OE# A22-59791-003</p>	 <p>09-0652 LIQUID HOSE Freightliner Century Class/Columbia/Coronado OE# A22-57519-001</p>
 <p>09-0653 LIQUID HOSE Freightliner Century Class/Columbia/Coronado OE# A22-57592-000</p>	 <p>09-0654 LIQUID HOSE Freightliner Century Class/Columbia OE# A22-57592-002</p>

A/C HOSE ASSEMBLY

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

A/C HOSE ASSEMBLY



09-0655
LIQUID HOSE
Freightliner Columbia
OE# A22-57592-005



09-0656
LIQUID HOSE / DRIER to CONDENSER
Freightliner Columbia
OE# A22-52200-301, A22-52200-001



09-0657
LIQUID HOSE / DRIER to CONDENSER
Freightliner M2
OE# A22-57504-001



09-0658
LIQUID HOSE / DRIER to CONDENSER
Freightliner M2
OE# A22-57504-002



09-0659
LIQUID HOSE
Freightliner A/C Hose
OE# A22-57506-002



09-0660
LIQUID HOSE / DRIER to CONDENSER
Freightliner Columbia
OE# A22-60361-001











09-0661
LIQUID HOSE / DRIER to CONDENSER
Freightliner Columbia w/Detroit 60 engine
OE# A22-63684-000



09-0662
LIQUID HOSE / DRIER to EVAPORATOR
Freightliner Columbia
OE# A22-59999-001

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

 <p>09-0663 LIQUID HOSE / DRIER to J-BLOCK Freightliner M2 OE# A22-57505-000</p>	 <p>09-0664 LIQUID HOSE / DRIER to J-BLOCK Freightliner Columbia w/Detroit 60 engine OE# A22-62925-008</p>
 <p>09-0666 LIQUID HOSE / DRIER to J-BLOCK Freightliner Columbia OE# A22-59933-000</p>	 <p>09-0667 LIQUID HOSE / DRIER to J-BLOCK Freightliner A/C Hose OE# A22-57519-009</p>
 <p>09-0668 LIQUID HOSE / DRIER to J-BLOCK Freightliner A/C Hose OE# A22-57519-010</p>	 <p>09-0669 LIQUID HOSE / DRIER to J-BLOCK Freightliner A/C Hose OE# A22-57519-000</p>
 <p>09-0670 LIQUID HOSE Freightliner A/C Hose OE# A22-57505-001</p>	 <p>09-0671 LIQUID HOSE Freightliner A/C Hose OE# A22-59999-003</p>

A/C HOSE ASSEMBLY

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

A/C HOSE ASSEMBLY



09-0672
LIQUID HOSE
Replaces approx. 100" long aluminum style
Freightliner
OE# 05-19232-300



09-0673
LIQUID HOSE
Replaces approx. 110" long aluminum style
Freightliner
OE# 05-19232-301



09-0674
LIQUID HOSE
Replaces approx. 120" long aluminum style
Freightliner
OE# 05-19232-302




09-0675
LIQUID HOSE
Freightliner
OE# A22-59934-000



09-0676
LIQUID HOSE
Freightliner
OE# A22-60081-002



09-0677
LIQUID HOSE
Freightliner
OE# A22-60156-001











09-0678
LIQUID HOSE
Freightliner
OE# A22-47151-002



09-06100
SUCTION TUBE
Freightliner
OE# A22-63801-000

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

 <p>09-06101 SUCTION HOSE Freightliner OE# A22-65975-000</p>	 <p>09-06102 SUCTION TUBE Freightliner OE# A22-41322-051</p>
 <p>09-06103 SUCTION HOSE Freightliner OE# A22-59078-021</p>	 <p>09-06104 SUCTION TUBE Freightliner OE# A22-59808-002 NOTE: Protector not included</p>
 <p>09-06105 SUCTION TUBE Freightliner OE# A22-60079-000</p>	 <p>09-06106 SUCTION TUBE Freightliner OE# A22-60405-000</p>
 <p>09-06107 SUCTION TUBE Freightliner OE# A22-62580-000</p>	 <p>09-06108 SUCTION TUBE Freightliner OE# A22-71406-200 ; A22-66416-100</p>

A/C HOSE ASSEMBLY

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

A/C HOSE ASSEMBLY



09-06300
DISCHARGE HOSE
Freightliner
OE# A22-66632-101



09-06301
DISCHARGE HOSE
Freightliner
OE# A22-66834-004



09-06302
DISCHARGE HOSE
Freightliner
OE# A22-66834-008



09-06303
DISCHARGE HOSE
Freightliner
OE# A22-67862-000



09-06304
DISCHARGE HOSE
Freightliner
OE# A22-68540-000



09-06305
DISCHARGE HOSE
Freightliner
OE# A22-60416-004











09-06306
DISCHARGE HOSE
Freightliner
OE# A22-59792-003



09-06307
DISCHARGE HOSE
Freightliner
OE# A22-71408-203

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

 <p>09-0800 SUCTION HOSE Navistar ProStar OE# 3600647-C91 NOTE: Protector not included</p>	 <p>09-0801 SUCTION HOSE Navistar Prostar OE# 3590900-C91</p>
 <p>09-0820 DISCHARGE HOSE Navistar ProStar OE# 3612296-C92</p>	 <p>09-0821 DISCHARGE HOSE Navistar Prostar OE# 3565464-C91</p>
 <p>09-0822 DISCHARGE HOSE Navistar Prostar OE# 3565481-C91</p>	 <p>09-0823 DISCHARGE HOSE Navistar Prostar OE# 3582989-C91</p>
 <p>09-0824 DISCHARGE HOSE Navistar Prostar OE# 3582987-C92</p>	 <p>w/o switch</p> <p>09-0840 LIQUID HOSE Navistar ProStar OE# 3612298-C92</p>

A/C HOSE ASSEMBLY

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

A/C HOSE ASSEMBLY



09-0841
LIQUID HOSE
Navistar Prostar
OE# 3592145-C92



09-1000
SUCTION HOSE
Kenworth
OE# D9031-1478



09-1020
DISCHARGE HOSE
Length of hose: 43-1/4"
Kenworth
OE# D9031-1552; D9031-1543



09-1021
DISCHARGE HOSE
Length of hose: 47-1/4"
Kenworth
OE# D9031-1549; D9031-1541



09-1022
DISCHARGE HOSE
Length of hose: 50-1/4"
Kenworth
OE# D9031-1546



09-1023
DISCHARGE HOSE
Kenworth
OE# K342-805-1050-055-0










09-1024
DISCHARGE HOSE
Kenworth
OE# D9032-3618



09-1050
LIQUID HOSE
Kenworth
OE# F50-1653-0930

HOSE ASSEMBLIES

All fittings and tube assemblies manufactured in steel. Sorted in ascending order by part number (continued).

 <p>09-1400 DISCHARGE HOSE Peterbilt OE# D9027-3121; 18-04132-029</p>	 <p>09-1401 DISCHARGE HOSE Peterbilt OE# D9027-3127; 18-04132-035</p>
 <p>09-1402 DISCHARGE HOSE Peterbilt OE# D9027-8891; F50-6054-1425</p>	 <p>09-1403 DISCHARGE HOSE Peterbilt OE# D9027-2830; 18-04130-038</p>
 <p>09-1404 DISCHARGE HOSE Peterbilt OE# D9027-2834; 18-04130-042</p>	 <p>09-1405 DISCHARGE HOSE Peterbilt OE# D9027-2842; 18-04130-050</p>
 <p>09-1406 DISCHARGE HOSE (o'ring #0131) KW / Peterbilt OE# F50-6242-1475</p>	

A/C HOSE ASSEMBLY